

OK4 RS232-RS485 interface adapter

C1	10µF, 10V	R1	220Ω
C2	220µF, 16V	R2	220Ω
D1	1N4148	R3	47KΩ
D2	1N4148	R4	47KΩ
D3	BAT43	R5	68KΩ
D4	BAT43	R6	220KΩ
D5	BAT43	R7	220KΩ
D6	BAT43	U1	LTC485
D7	BAT43	Z1	5.1V, ½W
D8	BAT43	Z2	5.1V, 1W
J1	DB9-f	Z3	5.1V, 1W
J2	RJ11	C0	0.1µF
Q1	BC547B	J0	RJ11
Q2	BC547B	R0	510Ω

